



DIMENSION	1-1/2"	1-1/2"	2"	2"	3"	3"	4"	4"	6"	6"
	Class 150	Class 300	Class 150	Class 300	Class 150	Class 300	Class 150	Class 300	Class 150	Class 300
A (SR)	10-3/4"	11-1/4"	11-3/4"	12-1/4"	13-1/2"	13-7/8"	15-7/8"	16-5/8"	19-1/2"	20-3/16"
A (DA)	9-3/4"	10-1/4"	10-3/4"	11-3/8"	13-1/2"	13-7/8"	15-7/8"	16-5/8"	18-1/2"	19-3/16"
B (SR)	9-7/8"	9-7/8"	9-7/8"	9-7/8"	9-7/8"	9-7/8"	14"	14"	16-5/8"	16-5/8"
B (DA)	5-7/8"	5-7/8"	5-7/8"	5-7/8"	7-1/4"	7-1/4"	10-1/4"	10-1/4"	10-1/4"	10-1/4"
C (SR)	5"	5"	5-1/2"	5-7/8"	6-5/8"	6-5/8"	7-3/4"	8"	10"	10"
C (DA)	4-1/2"	4-1/2"	5-1/16"	5-3/8"	6-5/8"	6-5/8"	7-3/4"	8"	9-3/8"	9-3/8"
D	2-1/2"	3-1/16"	3"	3-1/4"	3-3/4"	4-1/8"	4-1/2"	5"	5-1/2"	6-1/4"
E	5"	6-1/8"	6"	6-1/2"	7-1/2"	8-1/4"	9"	10"	11"	12-1/2"
F (SR)	2-1/8"	2-1/8"	2-1/8"	2-1/8"	2-1/8"	2-1/8"	2-5/8"	2-5/8"	3-1/16"	3-1/16"
F (DA)	1-3/4"	1-3/4"	1-3/4"	1-3/4"	2-1/8"	2-1/8"	2-5/8"	2-5/8"	2-5/8"	2-5/8"
G (SR)	2-5/8"	2-5/8"	2-5/8"	2-5/8"	2-5/8"	2-5/8"	3"	3"	4-3/16"	4-3/16"
G (DA)	2-1/16"	2-1/16"	2-1/16"	2-1/16"	2-5/8"	2-5/8"	3"	3"	3"	3"
H (SR)	4"	4"	4"	4"	4"	4"	4-3/8"	4-3/8"	5-5/8"	5-5/8"
H (DA)	3-1/2"	3-1/2"	3-1/2"	3-1/2"	4"	4"	4-3/8"	4-3/8"	4-3/8"	4-3/8"
J (SR)	4-1/4"	4-1/4"	4-1/4"	4-1/4"	4-1/4"	4-1/4"	5-1/8"	5-1/8"	6-1/8"	6-1/8"
J (DA)	3-3/8"	3-3/8"	3-3/8"	3-3/8"	4-1/4"	4-1/4"	5-1/8"	5-1/8"	5-1/8"	5-1/8"
K	6-1/2"	7-1/2"	7"	8-1/2"	8"	11-1/8"	9"	12"	10-1/2"	15-7/8"
NOTE 1: "H" IS CENTERLINE TO OUTSIDE SURFACE OF SOLENOID- ADD 1-1/8" IF EQUIPPED WITH QUADRANT BREATHER BLOCK										
NOTE 2: ADD 3-1/8" TO "A" & "C" DIMENSIONS IF A DGO IS MOUNTED BETWEEN VALVE & C-SERIES ACTUATOR.										

Series F1-CS/SS with C-Series Pneumatic Actuator

